

REF.	DESC.
FA0701	STOPPER
FA0901	PUSHER PIN
FA1001	PUSHER SPRING
FA1201	MAGAZINE RETAINER
FA1401	LATCH
FA2001	SPRING
FB2501	PISTON STOP
FB6501	COMPRESSION SPRING
FE1201	EXHAUST CAP RING
KF0412C	FLAT HD.BOLT M4×0.7-12L
KF0510	FLAT HD.BOLT M5×0.8-10L
KM0306	HEX.SOC.HD.BOLT M3×0.5-6L
KM0406	HEX.SOC.HD.BOLT M4×0.7-6L
KM0408	HEX.SOC.HD.BOLT M4×0.7-8L
KM0410	HEX.SOC.HD.BOLT M4×0.7-10L
KM0414	HEX.SOC.HD.BOLT M4×0.7-14L
KM0516	HEX.SOC.HD.BOLT M5×0.8-16L
KM0520	HEX.SOC.HD.BOLT M5×0.8-20L
KS2008	SPRING PIN §2-8L
OA003A	O-RING ARP568-003
OA004A	O-RING ARP568-004
OA120A	O-RING ARP568-120
OA126A	O-RING ARP568-126
OA204B	O-RING ARP568-204
OB172H	O-RING 16.5×3.0
OB221A	O-RING 22×3
OB271A	O-RING 26.8×2.4
OP010A	O-RING P10
OP012A	O-RING P12
OS030A	O-RING S-30
PA1901	PIN
PA2001	END CAP
PA3901	PIN
PC0601	SPRING
PC0701	PIN
PE0601	SPACER
PE0901	BUMPER

REF.	DESC.
PF1001	FIXED PLATE SEAT
PF1101	SUPPORT
PF1201	STOP PLATE
PF1401	NOZZLE
PH1201	FIXED PLATE
PI0101	MAGAZINE SEAT
PI0201	MAGAZINE CAP
PI0301	GUIDE PLATE
PI0301W	DRIVER ASSY.
PI0402	COVER PLATE
PI0601	DRIVER SET
PI0701	BAR
PI0802	SAFETY
PI0901	PIVOT
PI1001	PUSHER
PI1101	TRIGGER
PI1401	PIVOT
PI1501	CYLINDER
UE0101	BODY
UE0303	HEAD VALVE PISTON
UE0401	CAP SEAL
UE0701	COMPRESSION SPRING
UE1102W	TRIGGER VALVE ASSY.
UE1201	COLLAR
UE1302	COMPRESSION SPRING
UE1402	TRIGGER VALVE STEM
UE1501	SEAL
UE1601	TRIGGER VALVE GUIDE
UE1701	TRIGGER VALVE SEAT
UE3301	EXHAUST CAP
UG1001	MAIN PISTON
UG3501	PISTON STOP
UG5401	CYLINDER CAP
YE2501	E-RING §2.5
YG0501	SPRING WASHER §5
YL0508	LOCK NUT M5×0.8

