

REF.	DESC.
FA2401	PIN
FB2501	PISTON STOP
FE1201	EXHAUST CAP RING
FK1801	LATCH
FK2401	COMPRESSION SPRING
FS0201	DRIVER SET
FS0301W	DRIVER ASSY.
KF0308	FLAT HD.BOLT M3×0.5-8L
KF0510	FLAT HD.BOLT M5×0.8-10L
KM0405	HEX.SOC.HD.BOLT M4×0.7-5L
KM0406	HEX.SOC.HD.BOLT M4×0.7-6L
KM0408	HEX.SOC.HD.BOLT M4×0.7-8L
KM0412A	HEX.SOC.HD.BOLT M4×0.7-12L
KM0414	HEX.SOC.HD.BOLT M4×0.7-14L
KM0514	HEX.SOC.HD.BOLT M5×0.8-14L
KM0516	HEX.SOC.HD.BOLT M5×0.8-16L
KM0520	HEX.SOC.HD.BOLT M5×0.8-20L
OA003A	O-RING ARP568-003
OA004A	O-RING ARP568-004
OA126A	O-RING ARP568-126
OA204B	O-RING ARP568-204
OB221A	O-RING 22×3
OB271A	O-RING 26.8×2.4
OP010A	O-RING P10
OP012A	O-RING P12
OP016H	O-RING 15.8×2.4
OS030A	O-RING S-30
PA1601	NOZZLE
PA1901	PIN
PA2001	END CAP
PE0901	BUMPER
PF1601	SPRING
PF1701	SAFETY LEVER
PF1801	PIN
PH0901	CYLINDER
PH1501	MAGAZINE SEAT

REF.	DESC.
PH1601	MAGAZINE CAP
PH1701	SPACER
PH1801	DISTANCE SET
PH1901	PUSHER
PH2001	MAGAZINE RETAINER
PH2101	FIXED PLATE
PH2201	SUPPORT
PH2301	COVER
PH2401	COMPRESSION SPRING
PH2601	PUSHER PIN
PH2701	PUSHER SPRING
PH2801	PIVOT
PH3001	GUIDE PLATE
PH3101	CYLINDER CAP
PH3201	COVER PLATE
PH3801	NUT PLATE
UE0101	BODY
UE0303	HEAD VALVE PISTON
UE0401	CAP SEAL
UE0701	COMPRESSION SPRING
UE1101W	TRIGGER VALVE ASSY.
UE1201	COLLAR
UE1301	COMPRESSION SPRING
UE1401	TRIGGER VALVE STEM
UE1501	SEAL
UE1601	TRIGGER VALVE GUIDE
UE1701	TRIGGER VALVE SEAT
UE1801	TRIGGER
UE3301	EXHAUST CAP
UG3501	PISTON STOP
YA0302	HEX BAR WRENCH D3
YE2501	E-RING §2.5
YG0401	SPRING WASHER §4
YG0501	SPRING WASHER §5
YL0508	LOCK NUT M5×0.8

