




**simHM12 P 180 W**  
**Despiece - Spare part list**

| <b>NUM.</b> | <b>REF.</b> | <b>DESC.</b>          |
|-------------|-------------|-----------------------|
| 1           | 2743010-B   | HANDLE SET            |
| 2           | 2114032-G   | RUBBER                |
| 3           | 9003039     | NUT                   |
| 4           | 2680502     | HEATER SET            |
| 5           | 2743041-B   | TRIGGER SET           |
| 6           | 2552040     | STAND                 |
| 7           | 2612040     | STAND                 |
| 8           | 9003017     | SCREW                 |
| 9           | 2613030     | CORD FIXER            |
| 10          | 9002072     | PLUG A                |
| 11          | 2527020     | STROKE ADJUSTOR NUT   |
| 12          | 9003052-032 | STROKE ADJUSTOR SCREW |




**simHM12 P 180 W | Explosionado - Exploded view**



**simHM12 P 180 W**  
Despiece calentador - Heater spare part list

| NUM. | REF.         | DESC.          |
|------|--------------|----------------|
| 1    | 2653020-B    | -              |
| 2    | 2682012-PA   | -              |
| 3    | 2881060      | -              |
| 4    | 2105040C230  | -              |
| 5    | 2105021B     | -              |
| 6    | 2662013      | -              |
| 7    | 2662100      | INLET TUBE SET |
| 8    | 9002003-CE1X | -              |
| 9    | 2100511-W    | -              |
| 10   | 2154055-R    | ON/OFF SWITCH  |
| 11   | 9002006      | -              |
| 12   | 9001011DAB   | POWER CORD     |
| 13   | 2105010CX    | -              |
| 14   | 2331820-B    | NR-21 NOZZLE   |



**simHM12 P 180 W | Explosionado calentador - Heater exploded view**