

| NUM. | REF.     | DESC.                   | NUM. | REF.    | DESC.                 |
|------|----------|-------------------------|------|---------|-----------------------|
| 1    | AC01001  | SET SCREW               | 49   | AC50049 | ROLLER PIN            |
| 3    | AC01003  | SHAKEPROOF LOCK WASHER  | 50   | AC50050 | LOWER JAW             |
| 4    | AC01004  | AIR DEFLECTOR           | 51   | AC50051 | FEEDER ARM            |
| 5    | AC01005  | REAR VALVE SEAT         | 56   | AC50056 | WASHER                |
| 6    | AC01006  | O-RING                  | 57   | AC50057 | NUT                   |
| 7    | AC01007  | THROTTLE SPRING         | 59   | AC01059 | INLET BUSHING         |
| 8    | AC01008  | THROTTLE SPRING LOCATOR | 64   | AC50064 | SOCKET HEAD CAP SCREW |
| 9    | AC01009  | THROTTLE VALVE SCREW    | 67   | AC01067 | NUT                   |
| 10   | AC01010  | VALVE SCREW WASHER      | 68   | AC50068 | PUSHER                |
| 11   | AC01011  | O-RING SUPPORT          | 69   | AC50069 | STOP RING             |
| 12   | AC01012  | O-RING                  | 70   | AC50070 | SPRING                |
| 13   | AC01013  | O-RING CENTER SUPPORT   | 71   | AC50071 | FEEDER ARM SCREW      |
| 14   | AC01014  | THROTTLE VALVE SPACER   | 73   | AC50073 | MAGAZINE BODY         |
| 16   | AC01016  | FRONT VALVE SEAT        | 74   | AC50074 | JAW BOLT              |
| 17   | AC01017  | THROTTLE STEM           | 75   | AC50075 | MAGAZINE SPRING       |
| 18   | AC01018  | BUTTON HEAD CAP SCREW   | 76   | AC50076 | MAGAZINE SHOE         |
| 20   | AC01020  | TRIGGER GUARD           | 77   | AC50077 | ROLL PIN              |
| 21   | AC50021  | FLEXLOC NUT             | 78A  | AC5078A | MAGAZINE SHIM         |
| 23   | AC01023  | STUD                    | 78B  | AC5078B | MAGAZINE SHIM(THICK)  |
| 27   | AC50027  | HOUSING                 | 79   | AC01079 | WASHER                |
| 28   | AC01028  | SET SCREW               | 86   | AC01086 | PLATE SCREW           |
| 29   | AC50029  | O-RING                  | 117  | AC50117 | SPACER                |
| 30   | AC50030  | PISTON                  | 119  | AC50119 | O-RING                |
| 31   | AC50031  | CYLINDER GASKET         | 120  | AC50120 | ROLLER PIN            |
| 32   | AC50032  | PISTON STOP SPACER      | 121  | AC50121 | HANDLE                |
| 34   | AC50034  | CYLINDER                | 122  | AC50122 | HANDLE PIN            |
| 35R  | AC5035R  | SIDE PLATE (RIGHT)      | 123  | AC50123 | WASHER                |
| 35L  | AC5035L  | SIDE PLATE (LIGHT)      | 124  | AC50124 | PLATE NUT             |
| 36   | AC50036  | ROLL PIN                | 125  | AC50125 | WASHER                |
| 37   | AC01037S | TRIGGER                 | 126  | AC50126 | SCREW                 |
| 39   | AC50039  | SOCKET HEAD CAP SCREW   | 127  | AC50127 | NUT                   |
| 40   | AC50040  | UPPER JAW               | 201  | AC50201 | PISTON ASSY           |
| 41   | AC50041  | JAW BUSHING             | 202  | AC50202 | PISTON ROD ASSY       |
| 42   | AC50042  | SUPPORT PLATE           | 203  | AC50203 | FRAME ASSY            |
| 43   | AC50043  | LATCH PIN CLIP          | 204  | AC50204 | FEEDER GUIDE RAIL     |
| 44   | AC50044  | LATCH SPRING            | 205  | AC50205 | PUSHER ASSEMBLY       |
| 45   | AC50045  | LATCH                   | 206  | AC50206 | MAGAZINE ASSY.        |
| 46   | AC50046  | ROLLER                  | 208  | AC01208 | THROTTLE ASSY.        |
| 47   | AC50047  | FEEDER BLADE            | 209  | AC50209 | PISTON SPACER ASSY    |
| 48   | AC50048  | PISTON ROD              |      |         |                       |



